



## Installing Tent Stake Chuck or Square Tube to Multi Pro™ and Multi ProXA™ Post Driver



301155



301425

### Parts Included in this Chuck Kit:

- Chuck: Tent Stake Chuck (301155) or Square Tube Chuck for Multi-Pro and Multi-Pro XA (301425)
- (4) Chuck Bolts (300717-4)
- (4) Lock Washers (300750-4)

### Tools Required:

- Socket Wrench with 1/4" Hex Bit
- Torque Wrench with 1/4" Hex Bit (in/lbs or Nm)
- Loctite Primer 7649 and Threadlocker 243



## Removing the Existing Chuck

Remove the Chuck Lok™ nut from the chuck.



Then using a 1/4" hex drive bit remove the 4 chuck bolts and lock washers and detach the chuck.

Using acetone or cleaning solvent clean any dried threadlocker from them and the bolt holes to ensure all debris from previous installation has been removed.



Replace the Chuck Lok™ nut onto the standard chuck and store in a convenient place for future use.



Place lock washer (300750-4) over each chuck bolt (300717-4) and apply Loctite 7649 Primer to threads of each chuck bolt and to chuck bolt holes on the lower body. Wait for primer to dry, then apply Loctite 243 thread locker to bolts and bolt holes.



Position the new chuck (301155) or (301425) and start, by hand, each bolt with washer. Then tighten them with a 1/4" hex wrench in a crossing pattern.

Finish the installation by using a torque wrench equipped with a 1/4" hex bit. Set the torque wrench to 251 in/pounds (28Nm) (21 ft/lbs) and torque the bolts in the same crossing pattern.



**RHINO TOOL COMPANY**

**P.O. Box 111**

**Kewanee, IL 61443**

**Main: 309-853-5555**

**Toll-Free: 866-707-1808**

**[www.rhinotool.com](http://www.rhinotool.com)**