


# HFD oil flow divider spare parts list



Pos.	Part No.	Description	Pcs.
1	RT8231814	Aluminium block	1
2	RT8231817	Nozzle 20 l.p.m. / 5 g.p.m.	1
2	RT8231818	Nozzle 30 l.p.m. / 8 g.p.m.	1
2	RT8231819	Nozzle 40 l.p.m. / 10 g.p.m.	1
2	RT8232799	Nozzle 45 l.p.m. / 12 g.p.m.	1
3	RT7421063	Fitting 1/2"x1/2" BSP	2
4	RT7521072	Seal ring 1/2"	8
5	RT7621037	Pipe plug 1/8" <i>Loctite 542</i>	2
6	RT7431815	Regulating valve <i>Incl. pos. 7. - 40 Nm</i>	1
7	RT7431816	Protective cap	1
8	RT7621075	Threaded plug 1/2" w/seal	1
9	RT7421733	Check valve	1
10	RT7401141	Q.R. coupling 1/2" BSP male	2
11	RT7401142	Q.R. coupling 1/2" BSP female	2
12	RT8741090	Tailhose 1/2"	2